

Seaglaze always recommend doing regular maintenance and checks on any products.

As with all mechanical equipment used on a daily basis, certain maintenance procedures are needed to ensure trouble free operation and longevity.

If required Installation and Spares Kits are available from Seaglaze. Please contact us for details.

Warnings:

- Only use warm soapy water to clean any of our products. Do not use products such as acetone or bleach etc.
- If any metal products come into contact with salt water we would always recommend that they are rinsed with fresh, clean water to remove any salt deposits that will build up and will accelerate corrosion.
- Wire wool should not be used on any Seaglaze products.
- Only Marine grade screws of the correct length should be used.
- If your door is glazed with Toughened Safety Glass it is important not to use knives or screw drivers around the glass as this could cause the pane to shatter.
- If the door is glazed with Acrylic please note that it is easily scratched by tools and scratches can not be removed.

Sliding Door Maintenance:

- Doors should be checked annually for alignment to ensure that the installation tolerances are maintained and any necessary adjustment to compensate for movement between the door and the frame should be made.

Frames:

All frames should be cleaned and checked every 3 months.

- Check all frames for any paint problems. This includes any chips, scratches, bubbling, discolouring, corrosion etc. Any issues should be addressed immediately. Seaglaze Instruction M400—Touch Up Paint may be useful.
- Check all frames for any signs of corrosion. If discovered early, we can advise remedial treatments to try and eliminate or delay the effects. Please see F020—Identifying and addressing corrosion
- Screw covers should be examined so they are fitting properly and there is no visible damage.

P.T.O

Sliding Door Maintenance (Continued) :

Handles:

Handles and Dogs should be checked every 6 months.

- Handles should be checked that they are fixed tightly and there is no movement.

Track:

- The inner track of the frame should be cleaned and any dirt should be removed. Check there are no marks on the frame which may indicate the door is not sliding properly.
- Drain holes should be cleaned and made sure they are completely free of any blockages.
- The brush seal must always be kept clean, any build up of dirt can cause leaking.

Glazing:

All glazing in doors should be checked every 6 months.

- All glass should be checked for chips and scratches, any damaged caused to the glass may result in the glass being weak and shattering.

Locks:

- Please see M300—Lock Maintenance for instructions

END OF INSTRUCTION

Options

Other useful instructions include...

- M400—Touch Up Paint
- M300—Lock Maintenance
- F020—Identifying and Addressing Corrosion

If in doubt, please email us at : support@seaglaze.co.uk